

Care and Maintenance

Scott Duraflow Powered Air Respirator

To maintain protection levels, optimise the effective lifetime of the system and avoid the additional cost of replacement, it is extremely important to carry out regular check and maintenance.

Before Use

- Pre-operational checks Before you power on the PAPR, ensure:
 - The battery pack is fitted and secure.
 - The approved filters are fitted in place.
 - The filters are within service life.
 - The headtop hose is connected and locked.
 - Visually inspect the whole set of equipment including the hose and headtop for damage and replace any defective parts. Ensure that the area around the filters is clear to provide airflow through the PAPR system.
- Power On Press and hold the Power button until the beep stops.
While you hold the power button, all the LEDs illuminate.
When the PAPR reaches 160 litres per minute (Lpm), the PAPR sounds three beeps, and the PAPR is ready to use.

Replace filter gaskets on an annual basis or when they become worn or damaged.

After Use

Carefully wipe clean the PAPR. You can clean the unit with any of the following cleaning solutions: soap and water, Distel solution, Incidin® Rapid cleaning solution, Incidur® Henkel solutions, some dioxycyclohexane-based cleaning solutions.



Part Number	Description
2031744	Standard Battery
2031745	Extended Battery
2031746	Charger
5062786	Standard Belt
5063597	Comfort Belt
5063596	Harness
1028174	Connector O Ring for Hose x 5
2031782	Filter Gasket x 2